2022

2022

BRUNO home

MY DESIGN MY LIFE MY LIVE 2022

DESIGN COLLECTION

INNOVATIVE FURNISHING SOLUTIONS
DEFINED TO SET NEW TRENDS
FOR THE CONTEMPORARY HOME

BRUNO home



ST8816F / SIDE TABLE
DG901 / SHOW CASE

SF812 / SOFA
ST903 / COFFEE TABLE

SC802 / LEISURE CHAIR
ST8TSY/P / SIDE TABLE



SF812 / SOFA ST8816G / SIDE TABLE ST8815Y / SIDE TABLE

SF807L4 / SOFA
ST903 / COFFEE TABLE
ST8816F / SIDE TABLE
SC802 / LEISURE CHAIR



S#2117 / SOFA ST2117A / COFFEE TABLE
ST2115 / SIDE TABLE ST09C / SIDE TABLE ST090 / SIDE TABLE

SC2104 / LEISURE CHAIR ST2028 / SIDE TABLE DG019 / SHOWCASE



SF2200 / SOFA ST2104 / COFFEE TABLE ST909A / SIDE TABLE ST05D / SIDE TABLE

SC2025 / LEISURE CHAIR SJ2025 / POUF ST09E / SIDE TABLE



SF2100 / SOFA ST1756 / SIDE TABLE K2204 / SIDE BOARD
ST1821 / SIDE TABLE SC8037 / LEISURE CHAIR

ST225A / COFFEE TABLE ST225B / COFFEE TABLE ST2115 / SIDE TABLE



SF2100 / SOFA ST225A / COFFEE TABLE ST225B / COFFEE TABLE



SF2115 / SOFA JS993-B / SIDE TABLE K2202 / SIDE BOARD ST1786 / COFFEE TABLE JS993-A / SIDE TABLE

SC1901 / LEISURE CHAIR ST1757 / SIDE TABLE



SF2101 / SOFA ST221A / SIDE TABLE ST1930 / SIDE TABLE SC1924 / LEISURE CHAIR

ST221B / COFFEE TABLE JS993-A / SIDE TABLE

LIFE IS GOOD
ANINNOVATIVE LIVING ROOM



SF911/ SOFA ST911A / COFFEE TABLE
ST206B / SIDE TABLE SC802 / LEISURE CHAIR SJ901 / POUF ST206A / SIDE TABLE ST206C / SIDE TABLE



SF911 / SOFA ST911A/COFFEE TABLE ST206B / SIDE TABLE SC928 / LEISURE CHAIR
SJ901/POUF ST206A /SIDE TABLE ST206C /SIDE TABLE



SF911/ SOFA ST206A / SIDE TABLE ST206C / SIDE TABLE SJ901 / POUF

SF911/ SOFA



SF2117 / SOFA ST2112A / COFFEE TABLE ST2112B / COFFEE TABLE ST2112C / SIDE TABLE SC2104 / LEISURE CHAIR



SF2117 / SOFA ST916A / COFFEE TABLE

SC2104 / LEISURE CHAIR



SF2100 / SOFA　ST909B / SIDE TABLE　ST21138 / COFFEE TABLE

SC705A / LOUNGE CHAIR　ST05D/SIDE TABLE



SC03 / LEISURE CHAIR SF260 / SOFA ST8815E / COFFEE TABLE

ST8815C / SIDE TABLE



M911 / MIRROR
SF911A /SOFA

K4700 / SIDE BOARD
SJ911/ POUF

ST80SA/B/ COFFEE TABLE
ST8815Y / COFFEE TABLE

ST206B/C/-SIDE TABLE
SC802 / LEISURE CHAIR



SF911B / SOFA
ST206A/B/C / SIDE TABLE

ST911 / COFFEE TABLE
SC1733 / ARM CHAIR



SF3010G/SOFA ST202A / SIDE TABLE SF3010G/SOFA ST918B/SIDE TABLE SC1700 / ARM CHAIR ST913A / COFFFE TABLE



SC802/ LEISURE CHAIR ST901D / SIDE TABLE K4700 / SIDE BOARD

ST8168 / COFFEE TABLE SF1718L4 / SOFA ST09D / SIDE TABLE



SC802 / LEISURE CHAIR ST8815B / SIDE TABLE ST8815Y / COFFEE TABLE

ST1712 / COFFEE TABLE SF1709A / SOFA ST816A / COFFEE TABLE



SF2120 / SOFA ST215C / SIDE TABLE SC1926 / LEISURE CHAIR ST1819 / SIDE TABLE K2204 / SIDE BOARD

ST927/ COFFEE TABLE ST1770 / COFFEE TABLE ST806B / TEA TABLE



ST1770 / COFFEE TABLE ST927/ COFFEE TABLE



SF8066 / SOFA ST1957A / COFFEE TABLE ST1957B / COFFEE TABLE K1753B / SIDE BOARD

SF3102 / LEISURE CHAIR DG019 / SIDE BOARD ST1756 / SIDE TABLE



SF3110 / SOFA ST3121 / COFFEE TABLE ST2120A / COFFEE TABLE
JS992 / SIDE TABLE DG2117 / SIDE BOARD K2117 / TV STAND

SF3109E / LEISURE CHAIR ST1819 / SIDE TABLE



SF3110 / SOFA ST3121 / COFFEE TABLE
ST2120A / COFFEE TABLE JS992 / SIDE TABLE



SF3002 / SOFA ST8815Y / COFFEE TABLE ST218 / COFFEE TABLE
K2203 / SIDE BOARD SJ5010 / POUF

SC2030 / LEISURE CHAIR ST2120A / SIDE TABLE
ST8815P / SIDE TABLE ST8816G / SIDE TABLE

AND INTERNATIONAAL
LIFE STYLES



SF3002 / SOFA

SF3002 / SOFA ST2120A / SIDE TABLE



SF3118 / SOFA



ST1762 / COFFEE TABLE



SF3118 / SOFA K2204 / SIDE BOARD ST1902 / SIDE TABLE SC8050 / LEISURE CHAIR

ST1762 / COFFEE TABLE JS992 / SIDE TABLE



SF3015 / SOFA K2102 / SIDE BOARD ST1903 / SIDE TABLE SC2070 / LEISURE CHAIR

ST1709 / SIDE TABLE ST2102 / COFFEE TABLE ST88A / SIDE TABLE



ST1903 / SIDE TABLE SC2070 / LEISURE CHAIR



SF3015 / SOFA ST2102 / COFFEE TABLE



SF2008 / SOFA K2203 / SIDE BOARD ST1987 / SIDE TABLE SC1936 / LEISURE CHAIR

ST1765 / SIDE TABLE ST1784C / COFFEE TABLE ST1903 / SIDE TABLE



SF2031 / SOFA ST1764A / SIDE TABLE ST1764B / SIDE TABLE
ST1755 / COFFEE TABLE ST1768 / COFFEE TABLE

SC5069 / POUF SC5069 / LEISURE CHAIR ST1903 / SIDE TABLE



SF2205 / SOFA ST1759A / COFFEE TABLE ST1759B / COFFEE TABLE
ST1902 / SIDE TABLE SC916 / LEISURE CHAIR

K2204 / SIDE BOARD SC915 / LEISURE CHAIR



SF2205 / SOFA ST1759A / COFFEE TABLE ST1759B / COFFEE TABLE



SF3115 / SOFA ST1784B / COFFEE TABLE K1753B / SIDE BOARD

ST1757 / SIDE TABLE ST1821 / SIDE TABLE SC1930 / LEISURE CHAIR



SF1738L6 / SOFA ST904A / COFFEE TABLE

ST904B / COFFEE TABLE S213 / ARM CHAIR



SC8815G / ARM CHAIR ST8816G / SIDE TABLE

SF3103L4 / SOFA ST1712 / COFFEE TABLE ST8815Y / COFFEE TABLE ST8815P / SIDE TABLE



SF3103L4 / SOFA
ST8816G / SIDE TABLE

ST924A / COFFEE TABLE
ST924B / COFFEE TABLE

ST924C / COFFEE TABLE

SC909 / LEISURE CHAIR
K1702 / SIDE BOARD



SF3005L5 / SOFA ST802B / COFFEE TABLE
ST918B / SIDE TABLE ST3002A / COFFEE TABLE

ST802C / SIDE TABLE SC8815G / ARM CHAIR ST1701P / SIDE TABLE



5F3002L6 / SOFA ST1712 / COFFEE TABLE ST8815Y / COFFEE TABLE ST8815P / COFFEE TABLE

SC8815A / LEISURE CHAIR SJ8815A / POUF K808 / SIDE BOARD



SC8815A / LEISURE CHAIR SJ8815A / POUF ST809B / SIDE TABLE K1702 / SIDE BOARD

SF1750G / SOFA ST1712 / COFFEE TABLE ST8815Y / COFFEE TABLE ST8815P / COFFEE TABLE



SC8815A / LEISURE CHAIR
ST8815P / SIDE TABLE
SJ8815A / POUF
ST8079B / SIDE TABLE

SF3006L6 / SOFA
ST1700D / COFFEE TABLE
ST918A / COFFEE TABLE
ST918B / COFFEE TABLE



ST809B / SIDE TABLE ST809C / SIDE TABLE SF3004G / SOFA ST809B / SIDE TABLE

SF3007G / SOFA SC8671 / LEISURE CHAIR
ST802B / COFFFE TABLE ST8816G / SIDE TABLE



ST809B / SIDE TABLE
SC3073 / ARM CHAIR ST913A / COFFFE TABLE

SF3104B / SOFA ST913B / SIDE TABLE
SF3104G / SOFA ST8816G / SIDE TABLE S0029G / DISPLAY STAND



SF3015L7 / SOFA ST809B / SIDE TABLE ST809C / SIDE TABLE ST8816G / SIDE TABLE

ST802B / COFFFE TABLE SC916 / ARM CHAIR



SC3069 / LEISURE CHAIR ST809B / SIDE TABLE K1702 / SIDE BOARD

ST913A / COFFFE TABLE ST809C / SIDE TABLE SF3001G / SOFA ST8816G / SIDE TABLE



ST916B / COFFFE TABLE
SF3102L4 / SOFA ST8816G / SIDE TABLE

SC3102 / LEISURE CHAIR ST206B / SIDE TABLE ST206C / SIDE TABLE S0029G / DISPLAY STAND



ST809B / SIDE TABLE SC8815A / LEISURE CHAIR SF1740 / SOFA ST3002A / COFFEE TABLE



SV900 / TELEVISION CABINET SF17411L5 / SOFA ST900 / COFFFE TABLE ST01C / SIDETABLE S701D / SIDETABLE SC8815G / LEISURE CHAIR



SC3109 / LEISURE CHAIR SF3109G / SOFA ST30023A / COFFEE TABLE

K1702 / SIDE BOARD ST809B / SIDE TABLE ST809C / SIDE TABLE



SF916L6 / SOFA ST911B / SIDE TABLE ST916B / COFFEE TABLE ST8816G / SIDE TABLE /

SC8673 / LEISURE CHAIR ST809B / SIDE TABLE K1702 / SIDE BOARD



SF1725 / SOFA
ST09C/D /SIDE TABLE
ST1700A/B / COFFEE TABLE
SC916 / ARM CHAIR
ST202A / SIDE TABLE



SJ1725 / POUF
ST8815P / SIDE TABLE

SF1726 / SOFA
ST805A/B / COFFEE T

ST01C/D / SIDE TABLE
SC1722 / ARM CHAIR



SF801E / LEISURE CHAIR
SF801G / SOFA

ST8815P / SIDE TABLE

ST805A/B / COFFEE TABLE

SC801 / CHAIR
ST801D / SIDE TABLE



SC916 / ARM CHAIR
ST202B / SIDE TABLE

SF804 / SOFA
S206B/C / SIDE TABLE

ST202A / COFFEE TABLE
K906 / SIDE BOARD



SF804 / SOFA
S206B/C / SIDE TABLE

ST1700D / SIDE TABLE
ST202A / COFFEE TABLE

SC916 / ARM CHAIR
ST202B / SIDE TABLE



SF808 / SOFA
ST202A / SIDE TABLE

ST802C / SIDE TABLE
ST915A/B / COFFEE TABLE

K808 / SDIE BOARD
ST809B/C / SIDE TABLE

SC808 / ARM CHAIR
ST202B / SIDE TABLE



ST1700D / SIDE TABLE SF1720G / SOFA ST8816F / SIDE TABLE ST812C/ST808B / SIDE TABLE ST802A / COFFEE TABLE SC1720 / ARM CHAIR ST8816G / SIDE TABLE



SC8671 / LEISURE CHAIR

SF905 / SOFA
ST8816G / SIDE TABLE

ST8815Y/P / SIDE TABLE
ST8815E / COFFEE TABLE

SF8815 / SOFA
ST905 / SIDE TABLE



SC8815A / ARM CHAIR
ST8815P / SIDE TABLE

K1702 / SIDE BOARD
ST809A / SIDE TABLE

SF905G / SOFA
ST802C / SIDE TABLE


K813 / SIDE BOARD
SV813 / TV STAND
SF902L4 / SOFA
ST809B/C / SIDE TABLE
ST813 / COFFEE TABLE
SC8815G / LEISURE CHAIR
ST1701P / SIDE TABLE



SC916 / LEISURE CHAIR SC915 / LEISURE CHAIR ST802A / COFFEE TABLE

SF915 / SOFA



SC906 / ROCKING CHAIR



SC03 / ARM CHAIR
ST808A / COFFEE TABLE

SF2001 / SOFA
ST809B / SIDE TABLE



SC1700 / ARM CHAIR
ST09C/D / SIDE TABLE

SF2006 / SOFA
ST802A / COFFEE TABLE



SC705 / ARM CHAIR
ST8815F / SIDE TABLE

ST8815E / COFFEE TABLE
ST8815F / COFFEE TABLE

K1702 / SIDE BOARD
SF2005 / SOFA



SF807L4 / SOFA
ST802B / COFFEE TABLE

K906 / SIDE BOARD
ST802C / SIDE TABLE

SC8815A / ARM CHAIR



SC05 / ARM CHAIR
ST809B / SIDE TABLE

SF8673 / SOFA
ST8815E / COFFEE TABLE

K1702 / SIDE BOARD
ST8815Y/P / SIDE TABLE



SC8815G / ARM-CHAIR
ST812C / SIDE TABLE

SF814 / SOFA
ST812A / COFFEE TABLE



SC8815G / ARM CHAIR
ST812C / SIDE TABLE

SF2003 / SOFA
K906 / SIDE BOARD



SF2004 / SOFA
ST809B/C/ SIDE TABLE

K1702 / SIDE BOARD
ST812A / COFFEE TABLE

SC705 / ARM CHAIR
ST812C / SIDE TABLE



SF8817 / SOFA NT812 / NIGHT STAND ST812B / COFFEE TABLE

ST812A / COFFEE TABLE SF8815G / SOFA SC8816C / LEISURE CHAIR



SC8816C / LEISURE CHAIR NT812 / NIGHT STAND

ST812A / COFFEE TABLE SF8815G / SOFA


SC8815G / ARM CHAIR
ST8816F / SIDE TABLE
SF8815B / SOFA
ST8815B/C / COFFEE TABLE
ST8815E/Y/P/ SIDE TABLE
BE50B / POUF


SF1701G / SOFA
ST01C/D / SIDE TABLE
SC1700 / LEISURE CHAIR
K808 / SIDE BOARD
ST1701D / SIDE TABLE
SF801G / SOFA
ST1700D / SIDE TABLE


SF801E / LEISURE CHAIR
SC801 / LEISURE CHAIR
ST1701P / SIDET ABLE
K4700 / SIDE BOARD



SC1700 / LEISURE CHAIR ST605A/B / COFFEETABLE K808 / SIDE BOARD

SF1701G / SOFA ST01C/D / SIDE TABLE



/ SIDE BOARD SF807B / SOFA SF807L4 / SOFA ST802B / COFFEE TABLE
802 / TV STAND SC8671 / LEISURE CHAIR ST09E/F / SIDE TABLE ST1701P / COFFEE TABLE



K4700 / SIDE BOARD SC1700 / LEISURE CHAIR SF1700B / SOFA

ST1700 / COFFEE TABLE ST1700C / COFFEE TABLE



SF1718L4 / SOFA
M7805A / MIRROR K4700 / SIDE BOARD ST816A / COFFEE TABLE

SF1718F / SOFA ST09D / SIDE TABLE



SC8815G/ LEISURE CHAIR SF1709A / SOFA ST802B / COFFEE TABLE K808 / SIDE BOARD ST8815B/C / SIDE TABLE ST09D/ SIDE TABLE



K808 / SIDE BOARD SF809L6 / SOFA M7805A / MIRROR

ST802A / COFFEE TABLE ST1701H / SIDE TABLE SC8815G / LEISURE CHAIR



EC55A /LEISURECHAIR K808 / SIDE BOARD SF815G / SOFA ST816B / COFFEE TABLE ST701 / SIDE TABLE



K4803 / SIDE BOARD M7805A / MIRROR SF171SL6 / SOFA

ST8671 / COFFEE TABLE SC05C / LEISURE CHAIR



SC05C / LEISURE CHAIR

K808 / SIDE BOARD SF1717 / SOFA ST1710A/B/C/ COFFEETABLE



K705 / SIDE BOARD SF1723 / SOFA G129C / SIDE TABLE

G129A / COFFEE TABLE G129B / COFFEE TABLE SC05C / LEISURE CHAIR



V4700 / TV STAND SF8671F / SOFA ST13A / COFFEE TABLE

ST13B / COFFEE TABLE SC55A / LEISURE CHAIR



K4700 / SIDE BOARD SF8686G / SOFA
ST29D / SIDE TABLE ST816A / COFFEE TABLE

ST33B / SIDE TABLE ST33C / SIDE TABLE
ST05D / SIDE TABLE SC99A / SMALL CHAIR



M7805A / MIRROR SC805 / LEISURE CHAIR ST801D / SIDE TABLE SF806L5 / SOFA

ST806A / COFFEE TABLE SF8697G / SOFA ST806B / SIDE TABLE



SF808F / SOFA
ST09C / SIDE TABLE K808 / SIDE BOARD ST808A / COFFEE TABLE

ST09D / SIDE TABLE
SF808G / SOFA ST801D / SIDE TABLE SC808 / CHAIR



SC1714A / CHAIR SJ1714A / POUF ST701B / COFFEE TABLE

ST02A / SIDE TABLE HS09 / SOFA ST806A / SIDE TABLE SC03 / ARMCHAIR



M6803 / MIRROR
K808 / SIDE BOARD

B913 / TABLE 1695 / CHAIR



K1702 / SIDE BOARD

¥B5818 / TABLE C812 / CHAIR



DG2117 / SIDE BOARD

B2201 / DINING TABLE C241 / DINING CHAIR


K2200 / SIDE BOARD
B2100 / DINING TABLE
C1937 / DINING CHAIR



B2100 / DINING TABLE C1937 / DINING CHAIR





K2102 / SIDE BOARD

B2205 / DINING TABLE C1937 / DINING CHAIR



DG2200 / SIDE BOARD

B2203 / DINING TABLE C1944 / DINING CHAIR K2200 / SIDE BOARD



K2101 / SIDE BOARD

B2200 / DINING TABLE C7811A / DINING CHAIR DG2206 / SIDE BOARD



K1753B / SIDE BOARD

C241 / DINING CHAIR B1976 / DINING TABLE DG2206 / SIDE BOARD



K808 / SIDE BOARD C219 / DINING CHAIR B903 / DINING TABLE



K808 / SIDE BOARD

B912 / DINING TABLE C219 / DINING CHAIR



K808 / SIDE BOARD

B904 / DINING TABLE C918 / DINING CHAIR


M6803 / MIRRO
K1702 / SIDE BOARD
B6812 / TABLE
C204 / CHAIR
S0029 / SHOW CASE



M6803 / MIRRO
K808 / SIDE BOARD

B906 / TABLE C215 / CHAIR S0029 / SHOW CASE



M6803 / MIRROR
K1702 / SIDE BOARD

B7814 / TABLE
C205 / CHAIR

S0029 / SHOW CASE



B7014 / TABLE C205 / CHAIR



S0029 / SHOW CASE

M6803 / MIRROR
K1702 / SIDE BOARD B7814 / TABLE C209 / CHAIR



K906 / SIDE BOARD

YB901 / TABLE C907 / CHAIR



M6803 / MIRRO
K808 / SIDE BOARD

B909 / TABLE
LC95 / CHAIR



M6803 / MIRRO
K4700 / SIDE BOARD

B5811 / TABLE C5800 / CHAIR



K705 / SIDE BOARD M4802 / MIRROR B803B / TABLE C6815A / CHAIR



K4700 / SIDEBOARD M4802 / MIRROR

B5811 / TABLE C5810 / CHAIR



SV812 / SIDE BOARD B808 / TABLE LC95 / CHAIR

S0029G / SHOW CASE





B5818 / TABLE C7811 / CHAIR



SB802 / BED NT802 / NIGHT STAND

K1701C / SIDE BOARD ST1701P/ SIDETABLE SC802 / LEISURECHAIR



SB1931 / BED NT1815 / NIGHT STAND

JS993-B / SIDE TABLE SC07A / POUF



SB1928 / BED NT1917 / NIGHT STAND BE1702A / BEDSIDE BENCH

SD925 / DESK SC1938 / CHAIR



SB2120 / BED NT2121 / NIGHT STAND BE2120 / BEDSIDE BENCH SD925 / DESK SC1938 / CHAIR



SB3094 / BED NT1952 / NIGHT STAND

K06 / LEISURE CHAIR ST1821 / SIDE TABLE SX1926 / DISPLAY STAND




SC1924 / LEISURE CHAIR ST1821 / SIDE TABLE

SX1920 / DISPLAY STAND HB2234 / BED NT1810 / NIGHT STAND




SB922 / BED NT1810 / NIGHT STAND BE2116 / BEDSIDE BENCH
SC1871 / LEISURE CHAIR K2116 / SIDE BOARD



ST1757 / NIGHT STAND HB2233 / BED K069 / LEISURE CHAIR

ST1804A / DESK SC230 / CHAIR



HB2231 / BED NT2121 / NIGHT STAND AB057 / LEISURE CHAIR

SD1799 / DESK C4802 / CHAIR



HB2237 / BED NT1815 / NIGHT STAND SC230 / LEISURE CHAIR SD1931 / DESK SX1920 / SHOW CASE



SB941 / BED NT1815 / NIGHT STAND

SC1733 / LEISURE CHAIR ST1821 / SIDE TABLE SX1920 / DISPLAY STAND



SB913 / BED
NT929 / NIGHT STAND

K705 / SIDEB OARD

SC801 / ARM CHAIR
G102C / SIDE TABLE



SB910 / BED
BE910 / POUF

K1702 / SIDEBOARD M6803 / MIRROR
NT1702 / NIGHT STAND

SC916 / ARM CHAIR
ST202A / SIDE TABLE



SB5028 / BED
NT932 / NIGHT STAND

ST1701P / SIDE TABLE
SC05C / LEISURE CHAIR
K917 / SIDE BOARD



SB5011 / BED NT5812 / NIGHT STAND



SB5020 / BED NT1702 / NIGHT STAND

K1702 / SIDE BOARD BE50 / POUF


SC915 / ARM CHAIR
ST809B / SIDE TABLE
M6803 / MIRROR
K906 / SDIE BOARD
SB57 / BED
NT906 / NIGHT STAND



M6803 / MIRROR
K901 / SIDE BOARD

SC906 / ROCKING CHAIR
ST8815P / SIDE TABLE

SB2003 / BED
NT901 / NIGHT STAND



K813 / SIDE BOARD SB902 / BED NT813 / NIGHT STAND



SB903 / BED NT906 / NIGHT STAND

SF812 / SOFA ST809B / SIDE TABLE



SB08A / BED NT6001 / NIGHT STAND

SC05C / LEISURE CHAIR ST1701P / SIDE TABLE



SC815 / ARM CHAIR

SB42A/ BED NT50B / NIGHT STAND



SC805 / ARM CHAIR SB50B / BED NT50B / NIGHT STAND

K705 / SIDE BOARD



K1701C / SIDE BOARD SP88A / POUF SB56A / BED



SB705 / BED NT705 / NIGHT STAND
SC705 / LEISURE CHAIR K705 / SIDE BOARD



SCT714A / LEISURE CHAIR ST33C / SIDE TABLE SB703 / BED

ST33B / NIGHT STAND



SB706 / BED NT53A / NIGHT STAND

K1701C / SIDE BOARD ST1701P/ SIDETABLE SC805 / LEISURE CHAIR



SC99A / LEISURE CHAIR SB803 / BED NT53A / NIGHT STAND



SC05C/LEISURE CHAIR ST1701P/SIDE TABLE NT812/NIGHT STAND SB808/BED

K705/SIDE BOARD



The Code sideboard collection completes the homonymous system with a series of containers available in different configurations with open compartments, drawers, and hinged or folding doors. The versatility of the system can also be found in the variety of finishes, which give each sideboard a different style – more classic or more contemporary.

SD701 / DESK BC04 / CHAIR



SD704 / DESK BC03 / CHAIR